



Self-Contained Cooling Package Units

RLKB Standard Efficiency 7.5 through 15 Tons

Model #	Gross Cooling Capacity BTU/h (Kw)	EER	Nominal CFM
RLKB-A090CM00	90,000 (26.4)	9.2	2,900/3,200
RLKB-A120CM00	125,000 (36.6)	9.0	4,000/4,000
RLKB-A150CM00	152,000 (44.5)	9.0	4,800/4,800
RLKB-A181CM00	180,000 (52.7)	8.5	5,700/4,900

Twin Copeland Scroll Compressors. Forkable base rails for easy handling. One piece top for excellent water management. Easy access filters. Slide out blower assembly provides easy maintenance. Electric heater kits can be installed on the field or in the factory.

ACCESSORIES		
Model Number	Description	Factory Installation Available
RXRD-KDCM3	Economizer with Single Enthalpy	Yes
RXRX-AV02	Dual Enthalpy Kit	No
RXRD-LDCM3	Horizontal Economizer with Single Enthalpy	No
RXRX-AR02	Carbon Dioxide Sensor (Wall Mount)	No
RXRX-BFF02 (C, D, Y)	Power Exhaust	No
RXRF-HDA1	Manual Fresh Air Damper (Left Panel Mounted)	No
RXRF-FDB1	Motorized Fresh Air Damper	No
RXRX-AT02	Motor Kit for RXRF-HDA1	No
RXKG-BAE14	Roofcurb 14"	No
RXKG-BAE24	Roofcurb 24"	No
RXRX-CDCE50, RXRX-CFCE54, 56 & RXRX-CGCC12	Roofcurb Adapters	No
RXRN-AA61	Concentric Diffuser (Step-Down 18x28)	No
RXRN-AA66	Concentric Diffuser (Step-Down 18x32)	No
RXRN-AA71	Concentric Diffuser (Flush 18x28)	No
RXRN-AA76	Concentric Diffuser (Flush 18x32)	No
RXMC-CD04	Downflow Transition (Rectangular to Round)	No
RXMC-CE05	Downflow Transition (Rectangular to Rectangular 18x28)	No
RXMC-CF06	Downflow Transition (Rectangular to Rectangular 18x32)	No
RXMD-A04	Compressor Time Delay Relay Kit	Yes
RXRZ-A90	Low Ambient Control Kit	Yes
RXRX-AK01	High/Low Pressure Switch Kit	Yes
RXRX-AM01	Freeze Stat Kit	Yes
RXRX-AAD01C	Outdoor Coil Louver Kit	Yes

Warranty Information

Compressor - Five (5) Years

Electric Resistance Heater Elements - Five (5) Years

Any Other Part - One (1) Year

